



STADT HONEYWELL THERMOSTAT

SETTING PROGRAMMABLE THERMOSTAT

SETTING CURRENT DAY & TIME

- Press set current day/time
- Press day key to current day
- Press time up & down keys to correct time
- Press run program

PROGRAMMING THE FIRST DAY FOR HEATING

- Press the system key till heat is selected
- Press the wake key
- Press time up & down keys to set time for the heater to turn on
- Press the up & down keys next to the led display to set the temperature you wish your house to cool too when not at home
- Press the return key
- Press up & down keys to set time for the heater to turn back on
- Press the up & down keys next to the led display to set the temperature you wish to heat the house to
- Press sleep key
- Press the time up & down keys next to the led display to set the temperature you wish the house to cool when you are asleep
- Press run program

If you wish to keep the same program for the whole week, use the copy function

- Press the wake key
- Press the copy key
- Press the day key to move to the next day
- Press the copy key (done will be displayed)

Carry out the same procedure for each day

Batteries are in the back of the thermostat – need to take thermostat off the wall.

**FOR SERVICE AND TECHNICAL ASSISTANCE PLEASE CALL
03 98002431.**